

Basic painting work

Purpose: every painter works according to the same basic approach: safe, tidy, precise and easy to check.

Standard method

1

1. Preparation

Check the work order, substrate, materials, colour and protection.

2

2. Clean

Degrease and clean. Remove dust, dirt and loose paint residue.

3

3. Repair

Fill damaged areas and allow them to dry properly.

4

4. Sanding

Work from coarse to fine and create an even, matt surface.

5

5. Dust off and mask

Remove dust and neatly mask glass, fittings and edges.

6

6. Prime and finish coat

Apply primer where needed and apply the finish coat evenly in a fixed sequence.

7

7. Check and hand over

Check coverage, flow, lines and the tidiness of the work area.

Quality check

- Substrate clean, dry and sound
- Sanded surface even and dust-free
- Finish coat free from runs, streaks or missed spots
- Clean lines and no paint on adjacent surfaces
- Work area clean and materials tidied away

Practical example

Painting an interior frame

Degrease - fill - sand

Remove dust - mask

Prime where needed - finish coat

Check coverage and clean lines

Basic rules on site

- Always work in the same sequence.
- Do not skip any step, even under time pressure.
- Protect the surroundings before you start.
- Allow each coat to dry sufficiently.
- Only hand over after your own final inspection.

Fixed sequence

prepare -> clean -> repair -> sand ->
mask -> paint -> check

Suitable for instruction, onboarding and quality control